

<h1>HOW TO</h1>	Document #	Model name		
	HT00134E	ECO-55 / ECO-55ST		
Replace the L-250 thermodisc	Model number	Serial number		Date
	DP00070 / DP00071	100	to	...
		30-05-2017		

WARNING



HOT SURFACE. ALLOW TO COOL BEFORE SERVICING.

DANGER




DISCONNECT ALL SOURCE OF POWER BEFORE SERVICING THE STOVE.


NOTE

For part numbers, visit our website at: www.drolet.ca/en/parts/

TOOLS REQUIRED :







PARTS REQUIRED :



L-250 Thermodisc


PROCEDURE :





5 Unscrew, disconnect and remove thermodisc.

6 Follow previous steps in reverse order to reinstall.



This document is available for free download on the manufacturer's website. It is a copyrighted document. Re-sale is strictly prohibited. The manufacturer may update this document from time to time and cannot be responsible for problems, injuries, or damages arising out of the use of information contained in any document obtained from unauthorized sources.

Stove Builder International inc.
250, rue de Copenhague,
St-Augustin-de-Desmaures (Québec) Canada
G3A 2H3
Customer service : 418-908-8002
Email : tech@sbi-international.com
www.drolet.ca